

# **MRX**

# **MULTI-JAW DEMOLITION TOOL**

### **DEMOLITION SOLUTIONS**

Versatility is taken to a whole new level with the MRX. With three different interchangeable jaws – a concrete pulverizer, concrete cracker, and shear – the MRX is the answer to most primary and secondary demolition needs. The MRX is also equipped with a short center of gravity and 360-degree rotation for optimal maneuverability. The interchangeable jaws' designs facilitate improved penetration and rapid material downsizing, along with dual rotation motors\* for superior holding power and replaceable wear areas for longevity and minimized maintenance. 
\*standard on MRX 350 and above

## **MULTI-JAW DEMOLITION TOOL**



- Reverse Cylinder with internal hydraulic lines protects components from debris
- Speed Valve with internal hydraulic lines for durability
- Dual Rotation Motors for superior control and reliability
- Easy to Change Teeth to minimize downtime
- Cutting Blade to remove nuisance rebar

#### **CHOOSING THE RIGHT JAW - 5 MINUTE JAW CHANGES**

**CONCRETE PULVERIZER - CP** 

**CONCRETE CRACKER - CC** 

SHEAR JAW - SH







#### **SPECIFICATION TABLE**

Model	JAW	Weight (with jaw)*		Jaw Opening		Jaw Depth		Reach**		Min Excavator Weight - 3rd Member***		Max Excavator Weight - 3rd Member***	
		lbs	kg	in	mm	in	mm	ft	m	lbs	mTons	lbs	mTons
MRX 70	Shear (SH)	1,667	760	9.8	250	12.8	330	5.2	1.6	15,000	7	20,000	9
	Concrete Pulverizer (CP)	1,755	800	20.9	530	20.1	510	5.6	1.7	15,000	7	20,000	9
	Concrete Cracking (CC)	1,755	800	20.7	530	19.3	490	5.7	1.7	15,000	7	20,000	9
MRX 100	Shear (SH)	2,350	1,070	12.6	320	15.4	390	6.1	1.9	20,000	9	29,000	13
	Concrete Pulverizer (CP)	2,460	1,120	26.0	660	24.0	610	6.6	2.0	20,000	9	29,000	13
	Concrete Cracking (CC)	2,516	1,140	23.6	600	24.0	610	6.7	2.0	20,000	9	29,000	13
MRX 130	Shear (SH)	3,331	1,510	15.7	400	17.7	450	6.6	2.0	29,000	13	40,000	18
	Concrete Pulverizer (CP)	3,453	1,570	28.3	720	24.8	630	7.1	2.2	29,000	13	40,000	18
	Concrete Cracking (CC)	3,320	1,510	29.1	740	28.0	710	7.3	2.2	29,000	13	40,000	18
MRX 150	Shear (SH)	4,445	2,020	16.5	420	19.1	490	7.5	2.3	40,000	18	48,000	22
	Concrete Pulverizer (CP)	4,556	2,070	29.1	740	26.0	660	7.9	2.4	40,000	18	48,000	22
	Concrete Cracking (CC)	4,556	2,070	30.1	760	29.1	740	8.3	2.5	40,000	18	48,000	22
MRX 200	Shear (SH)	5,980	2,700	18.9	480	20.7	530	8.3	2.5	48,000	22	57,000	26
	Concrete Pulverizer (CP)	6,170	2,800	34.6	880	31.1	790	8.8	2.7	48,000	22	57,000	26
	Concrete Cracking (CC)	6,250	2,800	36.2	920	30.1	760	9.1	2.8	48,000	22	57,000	26
MRX 250	Shear (SH)	7,680	3,500	19.7	500	22.0	560	8.6	2.6	57,000	26	79,000	36
	Concrete Pulverizer (CP)	7,740	3,500	35.6	900	32.3	820	9.1	2.8	57,000	26	79,000	36
	Concrete Cracking (CC)	7,670	3,500	37.2	940	32.1	820	9.3	2.8	57,000	26	79,000	36
MRX 350	Shear (SH)	8,780	4,000	20.7	530	22.2	560	8.8	2.7	79,000	36	117,000	53
	Concrete Pulverizer (CP)	9,430	4,300	38.2	970	33.9	860	9.5	2.9	79,000	36	117,000	53
	Concrete Cracking (CC)	9,380	4,300	39.8	1,010	34.4	870	9.7	3.0	79,000	36	117,000	53
MRX 500	Shear (SH)	13,598	6,170	22.6	570	26.0	660	9.8	3.0	117,000	53	165,000	75
	Concrete Pulverizer (CP)	15,031	6,820	43.3	1,100	40.6	1,030	10.8	3.3	117,000	53	165,000	75
	Concrete Cracking (CC)	14,612	6,630	45.3	1,150	42.1	1,070	11.0	3.4	117,000	53	165,000	75
MRX 750	Shear (SH)	19,815	9,000	27.6	700	30.0	760	11.1	3.4	165,000	75	CONSULT FACTORY	
	Concrete Pulverizer (CP)	21,315	9,680	46.3	1,180	43.4	1,100	11.8	3.6	165,000	75	CONSULT FACTORY	
	Concrete Cracking (CC)	20,665	9,380	46.3	1,180	45.7	1,160	11.8	3.6	165,000	75	CONSULT FACTORY	

Weight includes standard excavator mounting bracket. Attachment weight may vary depending on mounting configuration as well as options.

<sup>\*\*\*</sup> Excavator weight range is a guide only. 2nd member configurations at or near min/max excavator weight and all 3rd member configurations must be preapproved by LaBounty. Quick couplers, short swing machines, long arms all impact carrier size recommendation.

LaBounty reserves the right to improve, update, or change the product specifications, appearance, or functional attributes without notice.

2021-06-10









 $<sup>^{**}</sup>$  Reach is measured from the attachment mounting pivot (boom or stick) forward to the end of the jaw.